




Installation quick start guide

0.04 - 11 gpm 5 - 90 psi
10 - 2500 l/h 0,4 - 6,2 bar



0.04 - 11 gpm 5 - 90 psi
10 - 2500 l/h 0,4 - 6,2 bar

