



# TL-400 Dispenser

## Two-Product Dispenser for Small On-Premise Laundry Facilities

The TL-400 dispenses two liquid laundry products into any top load or small capacity washing machine. It promotes the safe and economical use of laundry supplies by ensuring that an accurate amount of chemical is automatically added to every load. This dispenser also allows the user to select from four different programmable formulas so that varying soil loads can be dealt with more effectively.

The versatile TL-400 operates either manually or by electronic activation, and it features a programmable “double dose” lock-out function.

- Three modes of operation: Automatic, Sequence or Push Button
- Stopwatch-style programming
- Spring-loaded spinners
- Built-in load counter
- Pre-wired power and trigger signals
- Quick change squeeze tubes and captive thumb screws on pump covers
- Password protected



### Pump Information

|                    |                                                 |
|--------------------|-------------------------------------------------|
| Output             | 6.0 oz./min. (177mL/min)                        |
| Pump Tube Material | EPDM standard; optional silicon tubes available |
| Pump Spinner       | Spring-loaded, dual roller                      |



## Select from Three Modes of Operation

### Automatic Mode

When in Automatic Mode, the dispenser receives signals from supply outputs on the washing machine, and runs the corresponding pump for the programmed time in the formula selected.

### Sequence or Occurrence Mode

When in Sequence or Occurrence Mode, the supply signal wiring is connected to the hot and cold water valves of the washing machine. Based on the on-and-off valve cycling – sequence or occurrence – pumps run for the programmed time at the sequence or occurrence number assigned to the pump during the programming process. A signal qualifying time may be programmed to ignore short on/off cycling of the valves.

### Push Button Mode

When in Push Button Mode, the pump run times are programmed for each formula. A formula is activated by pressing the enter button on the dispenser. The formula number displayed will begin as soon as the enter button is pressed. Delays may be programmed to allow for washing machine fills.

| Model        | Description                             |
|--------------|-----------------------------------------|
| 00-07000-410 | TL w /1 pump                            |
| 00-07000-420 | TL w /2 pumps                           |
| 00-07878-410 | TL 1 X 6 oz./min. pump w /115V pwr cord |
| 00-07878-420 | TL 2 X 6 oz./min. pump w /115V pwr cord |