

AquaBlend Xtreme

Adjustable Pump – NPT



Description	Product code
AquaBlend Xtreme 0.2 - 2%	117947XT
AquaBlend Xtreme 0.8 - 5%	117948XT

*All references with standard Viton seals. For other seal materials please contact your Hydro distributor.

Maintenance Kits

Kit A: Dosage gasket kit

Dosage gasket



Light Usage:

Change every 6-12 months

Medium Usage:

Change every 6 months

Heavy Usage:

Change every 3-4 months

Model	Product code
AquaBlend Xtreme 0.2 - 2%	017210XT
AquaBlend Xtreme 0.8 - 5%	017220XT

Kit B: Wear kit

Dosing gasket,
shaft



Change
as needed

Model	Product code
AquaBlend Xtreme 0.2 - 2%	017211XT
AquaBlend Xtreme 0.8 - 5%	017221XT

Kit D: Check valve kit

Suction tube fitting
assembly (poppet,
O-ring, spring, fitting)



Change
as needed

Model	Product code
AquaBlend Xtreme 0.2 - 2%	017213XT
AquaBlend Xtreme 0.8 - 5%	017223XT

Kit E: Wear parts maintenance kit

Inner cylinder, shaft and
check valve



Change
as needed

Model	Product code
AquaBlend Xtreme 0.2 - 2%	017214XT
AquaBlend Xtreme 0.8 - 5%	017224XT

Kit G: Complete lower end kit

Dosing gasket, O-ring, shaft, gasket, inner cylinder and check valve, outer cylinder, ratio adjuster, O-rings, pin, filter, solution tube with strainer filter



Change
as needed

Model	Product code
AquaBlend Xtreme 0.2 - 2%	017216XT
AquaBlend Xtreme 0.8 - 5%	017226XT

Kit H: Motor piston kit

Motor piston assembly



Change
as needed

Model	Product code
AquaBlend Xtreme 0.2 - 2%	017200XT
AquaBlend Xtreme 0.8 - 5%	017200XT

Definitions

Light Usage: Pump is used once a week

Medium Usage: Pump is used 3-4 times each week

Heavy Usage: Pump is used 24 hours a day, seven days a week